


Measuring Guide


Quick2Fit - Perfect Fit Shutters

Perfect Fit Shutters are designed specifically for UPVC windows with a rubber bead and measuring for them is a very simple process. All you need is a pen, paper and a metal tape measure.


First, check the distance between the edge of the glass and any obstructions, such as window handles. ***This should be more than 25mm.***




Check also that the rubber beading ***does not extend into the glass area by more than 5mm.***



Next, *measure the depth of the window frame.* To do this, simply place a credit card over the corner of the frame and use a metal ruler to measure from the glass out to the edge of the card. This measurement will usually be between 18 and 24mm. ***This needs to be a minimum of 18mm.***





Then measure the **visible glass** area of each window.


Measure from the inside edges of the frame where the glass meets the rubber bead. **Do not include** any of the beading or rubber seals in your measurements.

Measure the across the top, the middle and the bottom of the glass to the nearest mm and write down the shortest measurement.

Simply repeat this step for the drop, measuring the left-hand side, the right-hand side and the centre.

Again, take a note of the shortest measurement.

Measure each window individually never assume that they're all the same size.



Next, we will need to know where your window handle is in relation to the glass. **Turn your handle to its fully open position, paying attention to where the handle pivots.**

Find the centre of the pivot point and **measure from the edge of the glass to the centre of the handle's pivot point.**

If your handle is at the bottom of the window, always measure from the **left** side of the glass. If the handle is on either the left or right, always measure from the **bottom** of the glass.

Different handle designs will pivot in different positions on their mounts, so always measure to the centre of the pivot point, not to the centre of the handle or the handle's mount.